


Dual Mode Precision Plunge Router (Push Button) - TRA001



Dual Mode Precision Plunge Router (Push Button) - TRA001

Diag. Ref.	Part No.	Description	Qty	Comments
1	TRA067	SCREW MOTOR TOP COVER		
2	TRA007	MOTOR TOP COVER		
3	TRA027	SPEED CONTROLLER		
4	TRC057	PLUG AND CORD		
5	TRA068	BRUSH CONNECTION B		
6	TRA069	BRUSH CONNECTION A		
7	TRA018	CORD RELIEF		
8, 9 & 10	TRA136	RACK POST GUIDE ASSEMBLY		
11	TRA071	SCREW, UPPER ARMATURE BEARING PLATE		
12	TRA016	UPPER ARMATURE BEARING PLATE		
13	TRA017	CORD RESTRAINT		
14	TRA072	SCREW, CORD RESTRAINT		
15,16,17,18,20 & 23	TRA135	SWITCH ASSEMBLY		
19	TRA034	GUIDE, DEPTH STOP SPRING		
21	TRA074	SCREW, SWITCH COVER, SHORT		
22	TRA075	SCREW, SWITCH COVER, LONG		
24	TRA077	CONNECTING WIRE, BROWN		
25	TRA078	CONNECTING WIRE, BLUE		
26	TRA079	SCREW, BRUSH HOLDER		
27	TRA056	BRUSH HOLDER		
28	TRA055	BRUSH		
29	TRA080	CAP, BRUSH HOLDER		
30	TRA081	SCREW, MICRO ADJUST KNOB		
31	TRA035	MICRO ADJUST KNOB		
32	TRA005	UPPER MOTOR BODY		
33	TRA003	FIELD		
34	TRA036-3	WORM GEAR		
34.2	TRA501	PIN		
34.3	TRA502	O-RING		
34.4	TRA503	FLAT WASHER		
34.5	TRA504	E-RING		
35	TRA082	SCREW, FIELD		
36 & 37	TRA127	MAGNET RING & MOUNT ASSEMBLY		
38	TRA085	UPPER ARMATURE BEARING		
39	TRA002	ARMATURE		
40	TRA024	FAN SHROUD		
41	TRA086	SCREW, LOWER ARMATURE BEARING PLATE		
42	TRA015	LOWER ARMATURE BEARING PLATE		
43	TRA014	LOWER ARMATURE BEARING		
44	TRA087	E RING		
45	TRA044	CLUTCH PLATE		
46	TRA043	PLUNGE PINION		
47	TRA037	WORM WHEEL, METRIC		

Dual Mode Precision Plunge Router (Push Button) - TRA001

Diag. Ref.	Part No.	Description	Qty	Comments
48	TRA152	SPRING, CLUTCH SHAFT OUTER		
49	TRA150	PLUNGE HANDLE CLUTCH SHAFT		
50	TRA139	PLUNGE HANDLE OUTER RUBBERISED		
51	TRA147	PLUNGE HANDLE SHAFT		
51.1	TRA141	PLUNGE SELECT PUSH BUTTON		
51.2	TRA142	PLUNGE SELECT BUTTON SPRING		
51.3	TRA143	PLUNGE SELCT BUTTON SCREW		
51.4	TRA144	PLUNGE HANDLE ROTOR		
51.5	TRA145	PLUNGE HANDLE STATOR		
51.6	TRA146	PLUNGE HANDLE LOCKOUT		
51.7	TRA149	PLUNGE HANDLE ROLL PIN X		
51.8	TRA151	SPRING, CLUTCH SHAFT INNER		
52	TRA140	PLUNGE HANDLE INNER		
53	TRA089	SCREW, PLUNGE HANDLE		
54	TRA090	SPRING, RELEASE RING		
55	TRA148	MICRO RELEASE RING		
56	TRA047	BUSH, METRIC WORM		
57, 58 & 76	TRA052	LOWER MOTOR BODY & BUSH ASSEMBLY		
59	TRA092	SPRING, DEPTH STOP		
60	TRA033	DEPTH STOP TUBE		
61	TRA058	PLUG, DEPTH STOP TUBE		
62	TRA046	FIXED HANDLE INNER		
63	TRA093	SCREW, FIXED HANDLE INNER		
64	TRA045	FIXED HANDLE OUTER		
65	TRA094	SCREW, FIXED HANDLE OUTER		
66	TRA032	DEPTH STOP BRASS PLUG		
67	TRA133	DEPTH STOP KNOB SPRING		
68, 69 & 70	TRA134	DEPTH KNOB ASSEMBLY		
71	TRA049	BOLT, PLUNGE LOCK		
72	TRA098	SCREW, PLUNGE LOCK LEVER PLATE		
73	TRA050	PLATE, PLUNGE LOCK LEVER		
74	TRA048	PLUNGE LOCK LEVER		
75	TRA099	SCREW, PLUNGE LOCK LEVER		
77	TRA101	SCREW, MOTOR BODY		
78	TRA013	CHUCK ASSEMBLY		
79	TRA104	SPRING, SHAFT LOCK (INNER)		
80	TRA026	PIN, SHAFT LOCK		
81	TRA105	SPRING, SHAFT LOCK (OUTER)		
82	TRA025	BUTTON, SHAFT LOCK		
83	TRA106	SCREW, SHAFT LOCK BUTTON		
84	TRA107	SCREW, CHIP SHIELD		
85	TRA022	CHIP SHIELD, REAR		
86	TRA108	LINER, RACK POST		

Dual Mode Precision Plunge Router (Push Button) - TRA001

Diag. Ref.	Part No.	Description	Qty	Comments
87	TRA109	SNAP RING, RACK POST		
88	TRA110	SPRING, RACK POST		
91	TRA064	KNOB, FENCE ATTACHMENT		
92	TRA111	SPRING, FENCE ATTACHMENT KNOB		
93	TRA021	CHIP SHIELD, FRONT		
94	TRA023	VACUUM SHIELD		
95	TRA030	TURRET WHEEL		
96	TRA112	NUT, TURRET WHEEL		
97	TRC028	TURRET		
98	TRA113	SCREW, TURRET WHEEL		
99	TRA114	SPRING, TURRET		
100	TRA029	TURRET DETENT BALL		
89, 90, 101, 103	TRA125	BASE & POST ASSEMBLY		
102	TRA115	SCREW, TURRET PIVOT		
104	TRA009	BASE PLATE		
105	TRA117	COACH BOLT, FENCE ATTACHMENT		
106	TRA118	SCREW. BASEPLATE		
107 - 111	TRA128	FENCE PLATE & CIRCLE CUTTER ASSEMBLY		
112 - 116	TRA126	FENCE ASSEMBLY		
117	TRA129	1/4" REDUCTION COLLET		
118	TRA124	1/2" CUTTER		
119	TRA066	SPANNER		
120	TRA505	WASHER		
124 - 130	TRA410	WINDER HANDLE ASSEMBLY		
131	TRA506	WASHER		
135	TRJ012	CHUCK ASSEMBLY 12MM		